

THE UNCANNY X-MEN and all Marvel characters: TM & copyright © 1992 Marvel Entertainment Group, Inc. All Rights Reserved. © 1992 Konami. All Rights Reserved.

© Konami Inc. 1991 Konami® is a trademark of Konami Co., Ltd.

Service & Parts

708-215-5100

Jerry Korbecki (Service Manager) ext. 122

Bob Arauz ext. 123

George Limonez ext. 123

INSTRUCTION MANUAL

KONAMI® is a trademark of Konami Industry Co., Ltd.

X-MEN 6 PLAYER PARTS LIST

Part #	Description
065003	X-MEN P.C.B. 6 Player
065100	X-MEN Control Panel 6 Player
065101	X-MEN Coin Door Decal
065200	X-MEN Marquee 6 Player
065300	Top Right Side Decal
065301	Top Left Side Decal
065302	X-MEN Logo Side Decal
065303	Middle Left Side Decal
065304	Bottom Right Side Decal
065305	Bottom Left Side Decal
065306	Front Decal
065307	Middle Right Side Decal
065700	Lower Bezel Decal
065701	X-MEN Monitor Top Bracket
065702	X-MEN Marquee & Mirror Bracket
065703	X-MEN Shelf Bracket
065704	X-MEN Corner Bracket
065705	X-MEN Monitor Glass Z-Bracket
065706	X-MEN Monitor Mount Bracket
065707	X-MEN Top Mirror Bracket
065708	X-MEN Control Panel Hinge
065709	X-MEN Bottom Marquee Bracket
30254	White Micro Button
30255	Red Micro Button
30256	Yellow Micro Button
30258	Blue Micro Button
30261	Micro Switch
30262	Micro Palnuts
30323	Red Micro Joystick
30324	Blue Micro Joystick
30325	Yellow Micro Joystick
30326	Wine Red Micro Joystick
30327	Sky Blue Micro Joystick
30328	Violet Micro Joystick
35201	I.S.O. Trans
35404	Complete Power Supply
40123	Coin Door 3 Slot with Meter
40124	Coin Door 3 Slot without Meter
40358	2-Way Mirror 48-24
40359	Monitor Glass 48-24.5
40360	Marquee Glass 48-8.5
40524	25 Inch Monitor R.D.S.N.

X-MEN 6 PLAYER TECHNICAL INFORMATION

TECHNICAL INFORMATION

- (1) Required power capacity GND-Vcc 5V 6A or more GND-(+12V)
 *See the Wiring Diagram
- *See the Wiring Diagram.
- (2) Output
 - R (red) analog, positive
 - G (green) analog, positive
 - B (blue) analog, positive
 - SYNC. H-V complexed, negative
- (3) There is no sound volume knob on the PCB. Sound level should be adjusted in the Manual Test mode. (See page 6.)
- (4) Handle with care.

PLAY INSTRUCTION

- 1 to 6 players can play at the same time.
- Choose the character you want to control out of the six individual X-MEN: Cyclops, Colossus, Wolverine, Storm, Nightcrawler and Dazzler.
- Deposit coins into the coin slot of the character you want and press ATTACK, JUMP or MUTANT POWER button to start.
- Control your character's movement using the 8-way joystick and attack enemies with ATTACK button. Press ATTACK button repeatedly to punch, kick, throw, back-attack the enemies. Use JUMP button to avoid enemy attack or defeat enemies from the air. Pressing JUMP button longer makes higher jump.
- Press ATTACK button while in the air for a flying attack.
- Press MUTANT POWER button to use a powerful Mutant Power of each individualistic character.
- Use of Mutant Power will consume 3 units of energy. When the energy left is less than 3 units, a power ball will be consumed instead. A bonus power ball can be obtained for defeating the boss enemy of each stage.
- Your energy will also be consumed when attacked by enemies. When it is used up, you will lose one life. The game is over when you have lost all the lives.
- There are 8 stages in all. You can continue the game as many times as you want. Any player can join at any time.

CONTROL PANEL LAYOUT

Control panel should be equipped with six sets of an 8-way joystick and three function buttons.



MUTANT POWER BUTTON







8-WAY JOYSTICK

ATTACK BUTTON


JUMP BUTTON

SELF TEST

Normal: "OK" will be displayed. Then the game will start.


Abnormal: "BAD" will be displayed and self test will repeat. If "16B BAD" is displayed, switch off and switch on again with TEST SWITCH (on the PCB) pressed.

X-MEN 6 PLAYER CABINET ASSEMBLY



- 1. Remove back service door with a phillips head screwdriver.
- 2. Remove shipping cover from the rear of the cabinet.
- 3. The rear monitor is shipped inside of the main cabinet and should be unfastened by using a 7/16 inch nut driver.
- 4. Remove the back service door from the monitor box. There are 3 sets of wires and one ground strap that must be fed through the front opening so electrical connections can be made after the rear monitor is fastened to the cabinet.
- 5. Using 6 bolts fasten rear monitor to main cabinet (as seen above). This is a TWO PERSON JOB. A 1/2 inch nut driver will be required.
- 6. Reach in and connect the wiring.
 - 1—2 wire connector (A.C.)
 - 1-5 wire connector (R.G.B.)
 - 1—13 wire connector (up front monitor adjustments)
 - 1—ground strap

X-MEN 6 PLAYER CABINET ASSEMBLY





- 1. Using the hinges bolted to the control panel box, attach them to the main cabinet with a 7/16 nut driver.
- 2. There are 4 electrical connections and one ground strap
 - 1-Attach ground strap to wing nut
 - 2-Attach the 6 position AMP connectors (R.G.B.)
 - 3—Attach the 9 position Molex connector (power)
 - 4—Attach the 4 position J.S.T. connector to the X-MEN PCB top right hand side (speakers)
 - 5—Attach the 6 position J.S.T. connector to the X-MEN PCB top left hand side (R.G.B.) (next to the 6th player control panel wires).
- 3. Latch the control panel box to the main cabinet via the coin door.


X-MEN 6 PLAYER WIRING HARNESS


	Solder Side ←			→ Parts Side	
BLACK	GND	Α	1	GND	BLACK
BLACK	GND	В	2	GND	BLACK
RED	+5V DC	С	3	+5V DC	RED
RED	+5V DC	D	4	+5V DC	RED
	NOT USED	E	5	NOT USED	
ORANGE	+ 12V DC	F	6	+12V DC	ORANGE
	*KEY	Н	7	*KEY	
	(EMPTY)	J	8	COIN COUNTER	GREEN/VIOLET
	(EMPTY)	К	9	(EMPTY)	
	(EMPTY)	L	10	(EMPTY)	
	(EMPTY)	М	11	(EMPTY)	
WHITE/GREEN	VIDEO GREEN	N	12	VIDEO RED	RED/WHITE
WHITE	VIDEO SYNC	Р	13	VIDEO BLUE	BLUE/WHITE
	(EMPTY)	R	14	VIDEO GROUND	BLACK
	(EMPTY)	S	15	TEST SWITCH	YELLOW
WHITE/VIOLET	COIN 2	Т	16	COIN 1	BLUE/VIOLET
	NOT USED	U	17	NOT USED	•
BLUE/YELLOW	2P UP	٧	18	1P UP	ORANGE/WHITE
VIOLET/YELLOW	2P DOWN	W	19	1P DOWN	BLACK/WHITE
ORANGE/GREEN	2P LEFT	Х	20	1P LEFT	RED/GRAY
ORANGE/YELLOW	2P RIGHT	Υ	21	1P RIGHT	WHITE/GRAY
BLACK/YELLOW	2P ATTACK	Z	22	1P ATTACK	RED/WHITE
ORANGE/GRAY	2P JUMP	а	23	1P JUMP	GREEN/ORANGE
ORANGE	2P MUTANT POWER	b	24	1P MUTANT POWER	RED/BLUE
	NOT USED	С	25	NOT USED	
	NOT USED	d	26	NOT USED	
BLACK	GND	е	27	GND	BLACK
BLACK	GND	f	28	GND	BLACK


(BASE COLOR/LINE COLOR)


























I







X-MEN 6 PLAYER SUB HARNESS FOR 3, 4, 5 & 6 PLAYERS

1			•					
3 3 Left White/Red 3 5 Left Brown/White 4 5 5 Right Brown/Red 5 5 Dup Brown/Yellow 5 5 Dup Brown/Orange 5 Dup Brown/Orange 5 Dup Brown/Orange 5 Dup Brown/Green 5 Dup Green/White Green/White Green/Green 5 Ground Black Green/Gre	-	1	Coin 3	Violet/White		1	Coin 5	Brown
A 3P Right		2	Empty			2	Empty	
1		3	3P Left	White/Red		3	5P Left	Brown/White
CN3 7 3P Attack White/Blue 6 5P Down Brown/Orange 5P 8 5P Jump Brown/Green 7 5P Attack Brown/Green 8 5P Jump Brown/Green 8 5P Jump Brown/Green 8 5P Jump Brown/Green 9 3P Mutant Power 10 Empty 11 Empty 12 Empty 13 Empty 14 Empty 15 Ground Black 15 Green/Black 15 Ground Black 15 Green/White 6P Jump Green/Black 16 GP Down Green/Black 17 GP Jump Green/Black 17 GP Jump Green/Black 18 GP Jump Green/Black 19 GP Jump Green/Black 10 GP Jump Green/Black 10 Empty 11 Empty 12 Empty 13 Empty 14 Empty 15 GP Jump Green/Black 16 GP Jump Green/Black 17 GP Attack Green/Orange 18 GP Jump Blue/Red 19 Jump Green/Black 10 Empty 11 Empty 12 Empty 11 Empty		4	3P Right	White/Yellow		4	5P Right	Brown/Red
CN3	*	5	3P Up	White/Black		5	5P Up	Brown/Yellow
SP SP SP SP SP SP SP SP		6	3P Down	White/Blue		6	5P Down	Brown/Orange
Second S	CN3	. 7	3P Attack	White/Brown	CN5	7	5P Attack	Brown/Blue
1	3P	8	3P Jump	White/Orange	5P	8	5P Jump	Brown/Green
1	CONTROLS	9	3P Mutant Power	White	CONTROLS	9	5P Mutant Power	Blue/Black
12		10	Empty			10	Empty	
13		11	Empty			11	Empty	
1		12	Empty			12	Empty	
1 Coin 4 Blue 1 Coin 6 Green	\$ **	13	Empty			13	Empty	
1		14	Empty			14	Empty	
2 Empty 3 4P Left Yellow/Brown 4 4P Right Brown/Black 5 4P Up Yellow/Green 6 4P Down Yellow/Red 6 6P Down Green/Black 6 4P Jump Yellow/White CN6 7 4P Attack Yellow/White CN6 7 6P Attack Green/Orange CONTROLS 9 4P Mutant Power Yellow CONTROLS 9 4P Mutant Power Yellow CONTROLS 9 6P Mutant Power Red/Black 10 Empty 11 Empty 12 Empty 13 Empty 14 Empty 14 Empty 15 Empty 16 Empty 17 Empty 18 Empty 19 Empty 19 Empty 19 Empty 10 Empty 11 Empty 11 Empty 12 Empty 13 Empty 14 Empty 15 Empty 16 Empty 17 Empty 18 Empty 19 Empty 19 Empty 19 Empty 10 Empty 11 Empty 11 Empty 12 Empty 13 Empty 14 Empty 15 Empty 16 Empty 17 Empty 18 Empty 19 Empty 19 Empty 19 Empty 10 Empty 11 Empty 11 Empty 12 Empty 13 Empty 14 Empty		15	Ground	Black		15	Ground	Black
2			1			,, ,		
2			1 0 : - 4	Dive			Coin 6	Green
3 4P Left Yellow/Brown 4 4P Right Brown/Black 5 4P Up Yellow/Green 6 4P Down Yellow/Red 6 4P Jump Yellow/Blue CN4 7 4P Attack Yellow/White CN6 7 6P Attack Green/Orange 4P 8 4P Jump Yellow/Blue CONTROLS 9 4P Mutant Power Yellow CONTROLS 9 4P Mutant Power Yellow CONTROLS 10 Empty 11 Empty 12 Empty 13 Empty 14 Empty 14 Empty 15 6P Left Green/White GP Right Green/White GP GP Up Green/Blue 6 6P Down Green/Blue 6 6P Down Green/Blue 6 6P Down Green/Orange 6 6P Down Green/Blue 6 6P Down Green/Bl		<u> </u>	4	Blue				diodii
4 4P Right Brown/Black 5 4P Up Yellow/Green 6 4P Down Yellow/Red 6 4P Down Yellow/White CN6 7 6P Attack Green/Orange 4P 8 4P Jump Yellow/Blue 6P 8 6P Jump Blue/Red CONTROLS 9 4P Mutant Power Yellow CONTROLS 9 6P Mutant Power Red/Black 10 Empty 11 Empty 12 Empty 12 Empty 13 Empty 14 Empty 14 Empty 15 Hollow/Black 16 P Right Green/Red 6 P Up Green/Blue 6 P Down Green/Blue 6 P Attack Green/Orange 6 P Jump Blue/Red 7 P Right Green/Red 6 P Up Green/Blue 6 P Attack Green/Orange 7 P Attack Green/Orange 8 P Jump Blue/Red 10 Empty 11 Empty 12 Empty 13 Empty 14 Empty 15 Empty 16 Empty 17 Empty 18 Empty 19 Empty 19 Empty 19 Empty 10 Empty 11 Empty 11 Empty 11 Empty 12 Empty 13 Empty 14 Empty			1	Valley / Droven			, ,	Green/White
5 4P Up Yellow/Green 6 4P Down Yellow/Red 7 4P Attack Yellow/White CN6 7 6P Attack Green/Orange 4P Sempty 10 Empty 11 Empty 12 Empty 13 Empty 14 Empty 15 6P Up Green/Black 6 6P Down Green/Blue 6 6P Down Green/Orange 6 6P Down Green/Orange 7 6P Attack Green/Orange 8 6P Jump Blue/Red 10 Empty 11 Empty 12 Empty 13 Empty 14 Empty 15 Empty 16 Empty 17 Empty 18 Empty 19 Empty 19 Empty 19 Empty 10 Empty 11 Empty 11 Empty 12 Empty 13 Empty 14 Empty			4					
CN4		 	4 ~				_	
CN4 7 4P Attack Yellow/White CN6 7 6P Attack Green/Orange 4P 8 4P Jump Yellow/Blue 6P 8 6P Jump Blue/Red CONTROLS 9 4P Mutant Power Yellow CONTROLS 9 6P Mutant Power Red/Black 10 Empty 11 Empty 11 Empty 12 Empty 12 Empty 13 Empty 13 Empty 14 Empty 14 Empty			- '			<u> </u>	1	
4P 8 4P Jump Yellow/Blue 6P 8 6P Jump Blue/Red CONTROLS 9 4P Mutant Power Yellow CONTROLS 9 6P Mutant Power Red/Black 10 Empty 11 Empty 11 Empty 12 Empty 12 Empty 13 Empty 14 Empty 14 Empty 15 Empty 16 Empty 17 Empty 18 Empty 19 Empty			-1		CNE		-	
CONTROLS 9 4P Mutant Power Yellow 10 Empty 11 Empty 12 Empty 13 Empty 14 Empty 15 Empty 16 Empty 17 Empty 18 Empty 19 6P Mutant Power Red/Black 10 Empty 11 Empty 12 Empty 13 Empty 14 Empty 15 Empty 16 Empty 17 Empty 18 Empty 19 Empty 19 Empty 10 Empty 11 Empty 12 Empty 13 Empty 14 Empty 15 Empty 16 Empty 17 Empty 18 Empty 19 Empty 19 Empty 10 Empty 11 Empty 12 Empty 13 Empty 14 Empty			4				1	_
10 Empty 10 Empty 11 Empty 12 Empty 13 Empty 14 Empty 14 Empty 15 Empty 16 Empty 17 Empty 18 Empty 19		- -	-i			<u> </u>	•	
11 Empty 11 Empty 12 Empty 12 Empty 13 Empty 13 Empty 14 Empty 14 Empty	CONTRULS		-	Yellow	CONTINUES	-	-	1100, 21001
12 Empty 13 Empty 14 Empty 15 Empty 16 Empty 17 Empty 18 Empty 19 Empty 19 Empty 10 Empty 11 Empty 11 Empty		-	-				1	
13 Empty 14 Empty 15 Empty 16 Empty 17 Empty 18 Empty 19 Empty 19 Empty 19 Empty			┥ ゛゛			1	1	
14 Empty 14 Empty		-	-				, -	
Plant			-1		-	—	-	
15 Ground Black		 	-1 ' '	Placie			4	Black
		15	_ Ground	DIAUK		10		

X-MEN 6 PLAYER

MANUAL TEST

(1) HOW TO START

After switching on the power, press the TEST SWITCH on the PCB or on the cabinet, and you will get the MAIN MENU of the Manual Test.

NOTE: Switching on with TEST SWITCH pressed causes the program in the EEPROM to be initialized to default.

(2) HOW TO RETURN TO THE GAME MODE

Select "EXIT" on the MAIN MENU then press player 1 ATTACK button to return to the game mode.

(3) ITEMS AND HOW TO SELECT

Use player 1 JOYSTICK to select the desired test and press player 1 ATTACK button to initiate testing. Press player 1 ATTACK button during or at the end of each test to return to the MAIN MENU.

I/O CHECK
SCREEN CHECK
COLOR CHECK
SOUND CHECK
MASK ROM CHECK
GAME OPTIONS
COIN OPTIONS
EXIT

PLAYER1 JOYSTICK = SELECT ITEM
PLAYER1 ATTACK = DO CHECK

(4) EXPLANATION OF THE ITEMS

1. I/O CHECK

Check all the joysticks and buttons to see "1" when switched on. Press player 1 and 2 ATTACK buttons at the same time to return to MAIN MENU.

2. SCREEN CHECK

Adjust focus, alignment, size, etc. using the cross-hatch screen.

3. COLOR CHECK

Adjust color brightness so that the specified area will be colorless.

4. SOUND CHECK

When "SOUND SCALE CHECK" is selected, a music scale sounds. At "SOUND CODE," push player 1 JOYSTICK right/left to change sound code.

5. MASK ROM CHECK

Roms will be checked one after another, and the message "OK" or "BAD" will be displayed on the screen.

6. GAME OPTIONS

Following screen will appear. Use player 1 JOYSTICK up/down to select the item and push JOYSTICK right/left to modify setting. Factory settings are shown in green, and modified results in red. (Settings below are not always the factory settings.) After modification is completed, select "SAVE AND EXIT" and press player 1 ATTACK button to save and return to MAIN MENU.

X-MEN 6 PLAYER

GAME OPTIONS

PLAYER'S LIFE

1 CREDIT 2 LIVES

DIFFICULTY LEVEL

SOUND VOLUME

4/MEDIUM

MAXIMUM MUTANT POWER 9

.....

SOUND IN ATTRACT MODE ALL THE TIME

FACTORY SETTINGS SAVE AND EXIT EXIT

PLYR1 JOYSTICK UP/DOWN=SELECT OPTION PLYR2 JOYSTICK RIGHT/LEFT=MODIFY SETTING

- ...Select from 1 to 9 lives. ...Select out of 8 levels.
- ...Maximum 9 or 3
- ... Adjust volume level between 0 and 30.
- ...Select out of 4 types:

"ALL THE TIME," "COMPLETELY OFF." "ONCE EVERY 3 CYCLES" or "ONCE EVERY 5 CYCLES"

- ... All the settings return to default.
- ... Save the modified settings.
- If you select "EXIT" instead of "SAVE AND EXIT" after modifying some settings, the message appears: "YOU DID NOT SAVE. DO YOU WANT TO SAVE? YES/NO." When you choose "YES," the screen shows "NOW SAVING" and returns to MAIN MENU. If you select "NO," "NO MODIFICATION" is shown and then MAIN MENU appears. COIN OPTIONS
- Selecting this item, the screen shows following options.

COIN OPTIONS

PREMIUM START

YES 1

STARTING

2 COINS 1 CREDIT

CONTINUATION

1 COIN 1 CREDIT

FACTORY SETTINGS

SAVE AND EXIT

EXIT

PLYR1 JOYSTICK UP/DOWN=SELECT OPTION PLYR2 JOYSTICK RIGHT/LEFT=MODIFY SETTING

..."NO" or "YES 1" to "YES 4"
(The number means the EXTRA coins necessary)


Same as above "GAME OPTIONS"

When you want "PREMIUM START" setting, choose the number of extra coins necessary for starting, then decide the coin setting for continuation. The number of coins for starting will be the sum of both numbers. If you do not set premium start, the number of coins necessary for starting and continuation will be the same.


*COIN SETTING OPTIONS

Coin(s)	1	1	1	1	1	1	1	2	2	2	3	3	3	à	4	4
Credit(s)	1	2	3	4	5	6	7	7	3	5	1_	2	4	1	3	5

X-MEN 6 PLAYER A.C. WIRING HARNESS



X-MEN 6 PLAYER PCB LAYOUT



THIS EQUIPMENT COMPLIES WITH THE REQUIREMENTS IN PART 15 OF FCC RULES FOR A CLASS A COMPUTING DEVICE. OPERATION OF THIS EQUIP-MENT IN A RESIDENTIAL AREA MAY CAUSE UNACCEPTABLE INTERFERENCE TO RADIO AND TV RECEPTION REQUIRING THE **OPERATOR TO TAKE WHATEVER** STEPS ARE NECESSARY/TO CORRECT THE INTERFERENCE. THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRED OPERATION.

KONAMI

900 Deerfield Parkway, Buffalo Grove, 60089-4510 Telephone: (708) 215-5100, Telex: 6871385 KONAM UW, Fax: (708) 215-5122